



## AutoFlare's Installation Process: Bonnet Scoop

*\*Please note the following is a general guide only for all models sold by AutoFlare. Due to the different style/design and fitting locations, small adjustments will need to be made.*

### *Tips:*

- *Allow yourself enough time (approx. 1-1.5 hours) for the installation process of the bonnet scoop. We don't want you to rush the process to be disappointed with the installation outcome. Rushing the application of the trims onto your ride could potentially result in poor fitment or misalign for the longevity of the part and its fitment.*
- *Do not install the bonnet scoop if your ride has gotten wet within the past 24 hours.*
- *When installing in cold weather, we recommend using a heat gun to warm the bonnet scoop before applying to your ride.*
- *Use the correct tools! Paintwork damage can easily happen when incorrect tools have been used.*

### Tools Required:

- A razor blade
- Heat gun

### Consumables Required:

- Adhesion promoter
- Car polish
- Microfibre cloth
- Double Sided Tape (Supplied)
- Masking tape

### Step 1 - Preparation (it's all about the prep!)

Remove any parts that will interfere with installing the bonnet scoop.

Thoroughly wash your ride (and thoroughly dry), paying extra attention to the area where the bonnet scoop will be applied ((for cars with dirt and grime embedded on the surface of the light, a clay cloth should be used to remove before install).

Polish the area after the panel is dry creating a clean surface.

Apply adhesion promoter to the inner top edge of all bonnet scoop. Allow to dry.

Apply double-sided tape to the top inner top edge of the bonnet scoop and cut any excess double-sided tape with a razor blade.

### Step 2- Installation

Place Bonnet Scoop onto bonnet panel.

Use the masking tape to mark the location/placement of the bonnet scoop on the bonnet panel. Remove the bonnet scoop and apply adhesion promoter inside the masked tape area on the bonnet. This will provide the best adhesion possible for both the bonnet scoop and the bonnet.

Leave some of the masking tape on for a guide of where to install the bonnet scoop.

Turn on heat gun and wave the heat over the double-sided tape to activate the glue and also over the bonnet. Do not exceed heat of 60 degrees.

Peel back a small amount of the double-sided tape on each end (Just enough for your fingers to grab it).

Making sure the bonnet scoop is sitting flush to all points of the bonnet, slowly peel off double sided tape applying pressure as you go.

Questions: If you require any further information or have inquires relating to the instalment process of our head light or tail light trims, please send us an email at [info@autoflare.com.au](mailto:info@autoflare.com.au). We are more than happy to assist.

**AutoFlare will not be held liable for any incorrect installations (that being not applied correctly or issues in future) or damage caused to parts occurring during the instalment process.**